

Brake Light Pro Supplementary Manual

Yamaha XT1200Z ABS TC Super Tenere 2010- (BLP-U01)

Secure the bike on a stand.



Remove the main seat and the black plastic cover.



Locate the rear light assembly connector.

(White, 3-pole connector)



Brake Light Pro

Supplementary Manual



Yamaha XT1200Z ABS TC Super Tenere 2010- (BLP-U01)

Cut the Yellow wire of the rear light assembly connector.

Connect the BLP Red wire to the Yellow wire end, which goes to the bike's main wiring harness.

Connect the BLP Green wire to the Yellow wire end, which goes to the rear light assembly.



Connect the BLP Black wire to the Black wire.



Typical position for the Brake Light Pro.

Secure the unit properly.

