

# Brake Light Pro

## Supplementary Manual



### Harley-Davidson Night Rod 2006- (BLP-U02)

Secure the bike on a stand.



Lift up the main seat and remove the rear seat.



Cut the Black wire of the rear light assembly connector.

Connect the BLP Black wire to the Black wire end, which goes to the bike main wiring harness.

Connect the BLP Blue wire to the Black wire end, which goes to the rear light assembly.

Connect the BLP Red wire to the Red/Yellow wire.



# Brake Light Pro

## Supplementary Manual



### Harley-Davidson Night Rod 2006- (BLP-U02)

Typical position for the Brake Light Pro.

Secure the unit properly.

