

Brake Light Pro Supplementary Manual



BMW S1000RR ABS TC 2015- (BLP-U05)

Secure the bike on a stand.



Remove the seats.

Remove the plastic cover from the tail
faring.

Open the cable tie which goes to the rear
light.



Cut the Grey/Red wire.

Connect the BLP Green wire to the
Grey/Red wire end, which goes to the
rear light assembly.



Brake Light Pro

Supplementary Manual



BMW S1000RR ABS TC 2015- (BLP-U05)

Connect the BLP Red wire to the Grey/Red wire end, which goes to the bike's main wiring harness.



Connect the BLP Black wire to the Brown wire.



Typical position for the Brake Light Pro.

Secure the unit properly.

