

Brake Light Pro Supplementary Manual

Honda CBF600S 2004-2007 (BLP-U01)

Secure the bike on a stand.




Remove the seats.



Locate the rear light assembly connector.

(Transparent, 9-pole connector on the left side)



Brake Light Pro Supplementary Manual



Honda CBF600S 2004-2007 (BLP-U01)

Cut the Green/Yellow wire.

Connect the BLP Red wire to the Green/Yellow wire end, which is at the wiring harness side.

Connect the BLP Green wire to the Green/Yellow wire end, which goes to the rear light assembly.



Connect the BLP Black wire to the Green wire.



Typical position for the Brake Light Pro.

Secure the unit properly.

