

QuickShifter easy Supplementary Manual



KTM SX 85 2010-2017 (iQSE-2 + QSH-CKP)

Secure the bike on a stand.



Remove the seat.

Remove the side fairings and the fuel tank.



Connect the two QSH Green wires to the White/Red and the White/Blue wires of the ignition pulse generator.



QuickShifter easy Supplementary Manual



KTM SX 85 2010-2017 (iQSE-2 + QSH-CKP)

Connect the QSH Red wire to the battery positive terminal via an on/off switch.

Connect the QSH Black wire to the battery negative terminal.

(We recommend using a 12V gel-type battery with 1.3Ah capacity or smaller.)



Mount the QSE sensor.

Make sure that there is at least 3 mm between the screw head and the chain.

(Replace the bolt with the one supplied. Place the conical washers at the two sides of the sensor like this: (O). Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

