

QuickShifter easy Supplementary Manual



KTM EXC 500 FI model 2012-2016 (iQSE-1 + QSH-F1E)

Secure the bike on a stand.



Remove the seat.

Remove the side fairings.

Remove the fuel tank.



Locate the fuel injector connectors under the fuel tank.

(Black, 2-pole connectors)



QuickShifter easy Supplementary Manual



KTM EXC 500 FI model 2012-2016 (iQSE-1 + QSH-F1E)

Connect the QSH connectors in-line with the injector connectors.



Connect the QSH Black wire terminal to the chassis ground.



Mount the QSE sensor under the bolt of gearbox shaft.

(Replace the bolt with the one supplied. Tighten the bolt in this position by about 6 Nm. If you do not have a torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



QuickShifter easy Supplementary Manual



KTM EXC 500 FI model 2012-2016 (iQSE-1 + QSH-F1E)

Typical position for the QuickShifter easy.

Secure the unit properly.

