

# QuickShifter easy Supplementary Manual



## KTM 125 Duke ABS 2011- (iQSE-W1 + QSH-F2A)

Secure the bike on a stand.



Remove the seats and remove the side fairings.



Locate the fuel injector connector under the fuel tank.

Connect the QSH connectors in-line with the injector connectors.

*(Make sure the QSH plugs marked with RED square are connected, and leave the unmarked coupler unused. You may connect the male and female plugs of the unused pair together or isolate with tape.)*



# QuickShifter easy Supplementary Manual



## KTM 125 Duke ABS 2011- (iQSE-W1 + QSH-F2A)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Place the sensor in the rod as shown.  
Tighten the nut by hand fully and then by a  
1/4 turn using a wrench but maximum to  
about 6 Nm.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

