

# QuickShifter easy Supplementary Manual

## BMW F800R ABS 2009- (iQSE-1 + QSH-F2D)

Secure the bike on a stand.



Remove the seat.

Remove the covers from the airbox.

Remove the battery and the airbox.



Locate the fuel injector connectors.

Plug the QSH connectors in-line with the  
fuel injector connectors.



# QuickShifter easy Supplementary Manual



## BMW F800R ABS 2009- (iQSE-1 + QSH-F2D)

Connect the QSH Black wire terminal to the battery negative terminal.

*(The picture on the right shows an alternative location, but we recommend using the battery negative terminal)*



Mount the QSE sensor.

*(Place the sensor in the rod as shown. Tighten the nut by hand fully and then by a 1/4 turn using a wrench but maximum to about 6 Nm.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

