

# QuickShifter easy Supplementary Manual

## BMW R1200RS ABS TC Euro 3 spec 2015-2018 (iQSE-1 + QSH-F2D)

Secure the bike on a stand.



Remove the seat and remove the black plastic covers below the fuel tank.

Remove the black plastic covers from the fuel injectors.



Locate the fuel injector connectors under the the black plastic covers.

Plug the QSH connectors in-line with the fuel injector connectors.

*(Black, 2-pole connectors)*



# QuickShifter easy Supplementary Manual



## BMW R1200RS ABS TC Euro 3 spec 2015-2018 (iQSE-1 + QSH-F2D)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Place the sensor in the rod as shown.  
Tighten the nut by hand fully and then by a  
1/4 turn using a wrench but maximum to  
about 6 Nm.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

