

QuickShifter easy Supplementary Manual

BMW R1200 ABS TC Euro 3 spec 2009-2014 (iQSE-1 + QSH-F2D)

Secure the bike on a stand.



Remove the seat and remove the black plastic covers below the fuel tank.



Locate the fuel injector connectors under the the black plastic covers.

Plug the QSH connectors in-line with the fuel injector connectors.

(Black, 2-pole connectors)



QuickShifter easy Supplementary Manual



BMW R1200 ABS TC Euro 3 spec 2009-2014 (iQSE-1 + QSH-F2D)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

(Replace the bolt with the one supplied. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

