

QuickShifter easy

Supplementary Manual



Ducati Superbike 999 2003-2007 (iQSE-1 + QSH-P2E)

Secure the bike on a stand.



Remove the side fairings.



Plug the QSH connectors in-line with the ignition coil connectors.



QuickShifter easy

Supplementary Manual



Ducati Superbike 999 2003-2007 (iQSE-1 + QSH-P2E)

Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the supplied washers at both sides of
the sensor. Tighten the bolt in this position
by about 6 Nm. If you do not have torque
wrench, tighten the bolt until the shift arm
is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

