

QuickShifter easy Supplementary Manual

Honda CB650F ABS 2014-2018 (iQSE-1 + QSH-P2T)

Secure the bike on a stand.



Remove the seat.

Remove the side fairings.



Locate the ignition coil connectors on the right side under the side fairing.



QuickShifter easy Supplementary Manual



Honda CB650F ABS 2014-2018 (iQSE-1 + QSH-P2T)

Take off the Black terminal from the coil.

Connect the Black terminal to the QSH Red wire terminal.

Connect the QSH Green terminal to this coil terminal.



Splice the QSH White wire to the Green/Blue wire of the coil by using the supplied red wire tap connector.



Take off the Black terminal from the other ignition coil.

Connect the QSH Green terminal to the empty ignition coil terminal.

Isolate the unused Black terminal with tape.



QuickShifter easy Supplementary Manual



Honda CB650F ABS 2014-2018 (iQSE-1 + QSH-P2T)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Place the sensor in the rod as shown.
Tighten the nut by hand fully and then by a
1/4 turn using a wrench but maximum to
about 6 Nm.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

