



SUPPLEMENTARY MANUAL

for QSE-1 + QSH-P2T

REMOVE THE
PASSANGER SEAT.



REMOVE THE
MAIN SEAT.



REMOVE THE COVERS
BELOW FUEL TANK.





SUPPLEMENTARY MANUAL

for QSE-1 + QSH-P2T

RELEASE SIDE COVERS
FROM FUEL TANK.



MOVE BACKWARD OR REMOVE
THE FUEL TANK.



TAKE OFF THE BLACK/WHITE
TERMINAL FROM ONE COIL.

CONNECT THE QSH GREEN
TERMINAL TO THIS COIL TERMINAL.



Honda CBF1000

2010-2015



CONNECT THE BLACK/WHITE TERMINAL TO THE QSH RED WIRE TERMINAL AND SECURE WITH TAPE.



TAKE OFF THE BLACK/WHITE TERMINAL FROM THE 2ND COIL.

CONNECT THE QSH GREEN TERMINAL TO THIS COIL TERMINAL.

ISOLATE THE UNUSED BLACK/WHITE TERMINAL WITH TAPE.



SPLICE THE QSH WHITE WIRE TO THE YELLOW/BLUE OR BLUE/YELLOW WIRE OF THE COIL BY USING THE SUPPLIED RED WIRE TAP CONNECTOR.

(REFER TO THE QSH-P2T INSTRUCTIONS)



Honda CBF1000

2010-2015



**CONNECT QSH BLACK WIRE
TERMINAL TO CHASSIS GROUND.**



MOUNT THE QSE SENSOR.
(REPLACE THE BOLT WITH THE ONE SUPPLIED.
PLACE THE CONICAL WASHERS AT THE TWO SIDES OF
THE SENSOR LIKE THIS: (O). TIGHTEN THE BOLT IN
THIS POSITION BY ABOUT 5 NM. IF YOU DO NOT HAVE
A TORQUE WRENCH, TIGHTEN THE BOLT UNTIL THE
SHIFT ARM IS TIGHT ON THE GEARBOX SHAFT.

FOR DIFFERENT MOUNTING OPTIONS,
REFER TO THE SENSOR INSTALL GUIDE.)



**TYPICAL POSITION FOR THE
QUICKSHIFTER EASY.**

