

QuickShifter easy Supplementary Manual



Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Remove the passanger seat.



Remove the main seat.



Remove the covers below the fuel tank.



QuickShifter easy Supplementary Manual



Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Release the side covers from the fuel tank.



Move backward or remove the fuel tank.



Take off the Black/White terminal from one coil.

Connect the QSH Green terminal to this coil terminal.



QuickShifter easy Supplementary Manual



Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Connect the Black/White terminal to the QSH Red wire terminal and secure with tape.



Take off the Black/White terminal from the 2nd coil.

Connect the QSH Green terminal to this coil terminal.

Isolate the unused Black/White terminal with tape.



Splice the QSH White wire to the Yellow/Blue or Blue/Yellow wire of the coil by using the supplied red wire tap connector.

(Refer to the QSH-P2T instructions)



QuickShifter easy Supplementary Manual



Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Connect the QSH Black wire terminal to the chassis ground.



Mount the QSE sensor.

*(Replace the bolt with the one supplied.
Place the conical washers at the two sides
of the sensor like this: (O). Tighten the bolt
in this position by about 6 Nm. If you do not
have torque wrench, tighten the bolt until
the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

