

Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Remove the passanger seat.



Remove the main seat.



Remove the covers below the fuel tank.



QuickShifter easy Supplementary Manual

Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Release the side covers from the fuel tank.



Move backward or remove the fuel tank.



Take off the Black/White terminal from one coil.

Connect the QSH Green terminal to this coil terminal.



QuickShifter easy Supplementary Manual



Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Connect the Black/White terminal to the QSH Red wire terminal and secure with tape.



Take off the Black/White terminal from the 2nd coil.

Connect the QSH Green terminal to this coil terminal.

Isolate the unused Black/White terminal with tape.



Splice the QSH White wire to the Yellow/Blue or Blue/Yellow wire of the coil by using the supplied red wire tap connector.

(Refer to the QSH-P2T instructions)



QuickShifter easy Supplementary Manual

Honda CBF1000 2010-2015 (iQSE-1 + QSH-P2T)

Connect the QSH Black wire terminal to the battery negative terminal.

(The picture on the right shows an alternative location, but we recommend using the battery negative terminal)



Mount the QSE sensor.

(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)



Typical position for the QuickShifter easy.

Secure the unit properly.

