# **QuickShifter easy** Supplementary Manual



### Honda NT700V ABS Deauville 2006-2015 (iQSE-1 + QSH-P2T)

Secure the bike on a stand.



Remove the seat.

Remove the covers from the fuel tank.

Remove the fuel tank and remove the airbox.



Locate the ignition coil connectors on the left side under the seat and under the airbox.



### **QuickShifter easy** Supplementary Manual



#### Honda NT700V ABS Deauville 2006-2015 (iQSE-1 + QSH-P2T)

Take off the Black/White terminal from the coil.

Connect the Black/White terminal to the QSH Red wire terminal.

Connect the QSH Green terminal to this coil terminal.



Splice the QSH White wire to the Blue/Yellow wire of the coil by using the supplied red wire tap connector.



Take off the Black/White terminal from the other ignition coil.

Connect the QSH Green terminal to the empty ignition coil terminal.

Isolate the unused Black/White terminal with tape.



# **QuickShifter easy** Supplementary Manual



### Honda NT700V ABS Deauville 2006-2015 (iQSE-1 + QSH-P2T)

Connect the QSH Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

(Place the sensor in the rod as shown. Tighten the nut by hand fully and then by a 1/4 turn using a wrench but maximum to about 6 Nm.)



Typical position for the QuickShifter easy.

Secure the unit properly.

