



# SUPPLEMENTARY MANUAL

for iQSE-1 + QSH-P4B

THIS MOTORCYCLE HAS A UNIQUE SHIFT ARM WHICH IS NOT COMPATIBLE WITH ANY QUICK SHIFTER SENSORS ON THE MARKET WITHOUT MODIFICATIONS. TO INSTALL THE QSE SENSOR, TAKE OFF THE SHIFT ARM FIRST AND USE AN ANGLE GRINDER TO MAKE ROOM FOR THE SENSOR. MAKE SURE THE NECK OF THE SENSOR DOES NOT TOUCH THE METAL LEVER AT ANY POINT.

ATTENTION: THIS MODIFICATION WILL MAKE THE SHIFT ARM WEAKER AND IT MAY AFFECT THE RE-SALE VALUE OF THE MOTORCYCLE. DO THIS ONLY AT YOUR OWN ACCEPTANCE AND RISK.



REPLACE THE BOLT WITH THE ONE SUPPLIED.

PLACE THE CONICAL WASHERS AT THE TWO SIDES OF THE SENSOR LIKE THIS: (O).

TIGHTEN THE BOLT IN THIS POSITION BY ABOUT 6 NM.

