

# QuickShifter easy

## Supplementary Manual



### Moto Morini X-Cape 650 ABS 2021- (iQSE-W1 + QSX-F2B)

Secure the bike on a stand.



Remove the seats.



Locate the fuel injector connectors under the fuel tank.

*(Grey, 2-pole connectors)*



# QuickShifter easy

## Supplementary Manual



### Moto Morini X-Cape 650 ABS 2021- (iQSE-W1 + QSX-F2B)

Connect the QSX connectors in-line with the fuel injector connectors.



Connect the QSX Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Replace the bolt with the one supplied. Place the supplied washers at both sides of the sensor. Tighten the bolt in this position by about 6 Nm. If you do not have a torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



# QuickShifter easy

## Supplementary Manual



Moto Morini X-Cape 650 ABS 2021- (iQSE-W1 + QSX-F2B)

Typical position for the QuickShifter easy.

Secure the unit properly.

