

# QuickShifter easy Supplementary Manual

## BMW F750GS ABS TC 2018- (iQSE-W1 + QSX-F2L)

Secure the bike on a stand.



Remove the seat.

Remove the cover from the fuel tank.

Remove the side fairings.

Remove the fuel tank and remove the  
airbox.



Locate the fuel injector connectors.

Plug the QSX connectors in-line with the  
fuel injector connectors.



# QuickShifter easy Supplementary Manual



## BMW F750GS ABS TC 2018- (iQSE-W1 + QSX-F2L)

Connect the QSX Black wire terminal to the battery negative terminal.



Mount the QSE sensor.

*(Replace the bolt with the one supplied. Tighten the bolt in this position by about 6 Nm. If you do not have a torque wrench, tighten the bolt until the shift arm is tight on the gearbox shaft.)*



Typical position for the QuickShifter easy.

Secure the unit properly.

