

# SpeedoHealer CAN

## Supplementary Manual



### BMW F800R ABS 2009- (SH-CAN)

Secure the bike on a stand.




Remove the dashboard and locate the dashboard connector.



Cut the White/Black wire about 2,5cm (1") of the connector.

Connect the SH Green wire to the White/Black wire end, which goes to the dashboard. Use a yellow butt connector.






# SpeedoHealer CAN

## Supplementary Manual




### BMW F800R ABS 2009- (SH-CAN)

Connect the SH Blue wire to the White/Black wire end, which is at the wiring harness side. Use a yellow butt connector.




Cut the White/Brown wire about 2,5cm (1") of the connector.

Connect the SH White wire to the White/Brown wire end, which goes to the dasboard. Use a yellow butt connector.



Connect the SH Yellow wire to the White/Brown wire end, which is at the wiring harness side. Use a yellow butt connector.






# SpeedoHealer CAN

## Supplementary Manual




### BMW F800R ABS 2009- (SH-CAN)

Splice the SH Red wire to the Grey/Blue wire of the light connector. Use a red wire tap connector.



Splice the SH Black wire to the Brown wire of the dashboard connector. Use a red wire tap connector.



Typical position for the SpeedoHealer CAN.

Secure the unit properly.

