

Honda CB900F Hornet 2002-2008 (SH-V4 + SH-H01)

Remove the seat.

Remove the frame covers below the fuel tank.

Lift up or remove the fuel tank.

Remove the air filter intake assembly at the left side.



Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.

(Transparent, 3-pole connectors in a dust boot at the left side)



Typical position for the SpeedoHealer.

Secure the unit properly.

