

# SpeedoHealer

## Supplementary Manual



### Suzuki AN400 Burgman 2007-2017 (SH-V4 + SH-S03)

Secure the bike on a stand.



Remove the helmet box cover.



Locate the vehicle speed sensor connectors.

Plug the SpeedoHealer connectors in-line with the vehicle speed sensor connectors.



# SpeedoHealer

## Supplementary Manual



Suzuki AN400 Burgman 2007-2017 (SH-V4 + SH-S03)

Typical position for the SpeedoHealer.

Secure the unit properly.

