

Honda VFR800X Crossrunner 2011- (SH-V4 + SH-U01)

Remove the seats.

Remove the fairings.



Remove the fuel tank.



Unplug the ABS ECU connector.

(Black connector behind the ABS unit)



Honda VFR800X Crossrunner 2011- (SH-V4 + SH-U01)

Cut the Pink/Green wire about 4cm (1.5") away from the connector.



Splice the SpeedoHealer White wire to the Pink/Green wire end, which goes to the ABS ECU connector.

Splice the SpeedoHealer Green wire to the Pink/Green wire end, which is at the wiring harness side.



Splice the SpeedoHealer Red wire to the Orange/Blue wire.

Splice the SpeedoHealer Black wire to the Green/Orange wire.



Honda VFR800X Crossrunner 2011- (SH-V4 + SH-U01)

Typical position for remote button.



Typical position for the SpeedoHealer.

Secure the unit properly.

