



SUPPLEMENTARY MANUAL

We recommend to connect the SH wires at the dashboard connector:

- 1) Cut the Pink/White wire about 2" away from the dashboard plug.
- 2) Connect the **SH White** to the Pink/White wire end at the wiring harness side.
- 3) Connect the **SH Green** to the Pink/White wire end at the speedometer side.
- 4) Connect the SH Black wire to the Black/White.
- 5) Connect the SH Red wire the White/Green.

When the installation is done, do the SH signal test procedure as follows:

- Have the ignition key OFF.
- Press SEL and keep it depressed while you turn the ignition ON.
 [t] (test) is now indicated. Release the button.
 Check: The speedometer should indicate a steady number other than 0.
- Move the bike back and forth so both wheels are turning. Check: [t] should be blinking as the wheels turn.

Note: [t] appears on the display like an [E] without the top horizontal bar.