

BMW R1200GS Euro 3 spec 2004-2012 (TB-U01)

Secure the bike on a stand.




Remove the seats.



Connect the TB terminals directly to the battery terminals.

Connect your accessories to the TB output terminal blocks.



ThunderBox

Supplementary Manual



BMW R1200GS Euro 3 spec 2004-2012 (TB-U01)

Optional:

If you wish to connect the White wire, splice it at the diagnostic connector to the Green/Blue wire.



Typical position for the ThunderBox.

Secure the unit properly.

