

Switchable Exhaust Servo Eliminator Supplementary Manual



Suzuki DL1000 ABS TC 2014-2020 (ESE-SW-S02)

Secure the bike on a stand.




Remove the seat.

Remove the side panel on the right side.

Locate the exhaust servo motor under the side panel.

Unplug the exhaust servo motor connectors.



Plug the ESE-SW connectors in-line with the exhaust servo motor connectors.



Switchable Exhaust Servo Eliminator Supplementary Manual




Suzuki DL1000 ABS TC 2014-2020 (ESE-SW-S02)

Connect the ESE-SW Red wire to the Orange wire of the rear brake light switch.



Mount the switch onto the handlebar.



Typical position of the Switchable Exhaust Servo Eliminator module.

Secure the unit properly.

