

Switchable Exhaust Servo Eliminator Supplementary Manual



Triumph Speed Triple 1200 RR ABS TC 2021- (ESE-SW-T03)

Secure the bike on a stand.



Locate the exhaust servo motor.

(At the right footpeg)



Unplug the exhaust servo motor
connectors.



Switchable Exhaust Servo Eliminator Supplementary Manual



Triumph Speed Triple 1200 RR ABS TC 2021- (ESE-SW-T03)

Plug the ESE-SW connectors in-line with the exhaust servo motor connectors.



Mount the switch onto the handlebar.



Typical position of the Switchable Exhaust Servo Eliminator module.

Secure the unit properly.

