

Switchable Exhaust Servo Eliminator Supplementary Manual



Yamaha MT-10 SP ABS TC 2017- (ESE-SW-Y01)

Secure the bike on a stand.



Remove the seat and locate the exhaust servo motor under the seat.



Unplug the exhaust servo motor connectors.

Plug the ESE-SW connectors in-line with the exhaust servo motor connectors.




Switchable Exhaust Servo Eliminator Supplementary Manual



Yamaha MT-10 SP ABS TC 2017- (ESE-SW-Y01)

Connect the ESE-SW Red wire to the Brown wire of the fuse box.



Mount the switch onto the handlebar.



Typical position of the Switchable Exhaust Servo Eliminator module.

Secure the unit properly.

