

Exhaust Servo Eliminator Supplementary Manual



MV Agusta Brutale 800 2014- (ESE-A01)

Secure the bike on a stand.



Locate the exhaust servo motor.

(Behind the radiator.)



Remove the the plastic cover.



Exhaust Servo Eliminator Supplementary Manual



MV Agusta Brutale 800 2014- (ESE-A01)

Remove the exhaust servo motor and unplug the exhaust servo motor connector.

Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.



Put back the plastic cover.

