

Exhaust Servo Eliminator Supplementary Manual



Aprilia Tuono V4 2017- (ESE-A03)

Locate the Exhaust Servo motor.

Unplug the Exhaust Servo motor
connector.

*(Black, 6-pole connector behind of the right
side fairing)*



Remove the Exhaust Servo motor.

Plug the ESE module to the 6-pole bike
harness connector.



Typical position for the Exhaust Servo
Eliminator.

Secure the unit properly.

