

# Exhaust Servo Eliminator Supplementary Manual


## BMW R1200RS ABS TC Euro 3 spec 2015-2018 (ESE-BM1)

Secure the bike on a stand.




Locate the exhaust servo motor.

*(At the right footpeg)*



Unplug the exhaust servo motor  
connector and remove the exhaust servo  
motor.

*(Black, 4-pole connector)*



# Exhaust Servo Eliminator Supplementary Manual



## BMW R1200RS ABS TC Euro 3 spec 2015-2018 (ESE-BM1)

Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.

