

Exhaust Servo Eliminator Supplementary Manual




Ducati Panigale V4 ABS TC 2024- (ESE-D07)

Secure the bike on a stand.




Remove the lower side fairing on the right side and locate the exhaust servo motor.



Remove the exhaust servo motor.

Unplug the exhaust servo motor connector.



Exhaust Servo Eliminator Supplementary Manual



Ducati Panigale V4 ABS TC 2024- (ESE-D07)

Plug the ESE connector to the exhaust servo motor connector.

Secure the unit properly.

