

Exhaust Servo Eliminator Supplementary Manual



Honda CBR600RR 2007-2009 (ESE-H03)

Remove the main seat.



Unplug the Exhaust Servo-motor
connectors.

*(Blue, 6-pole connector below main seat at
left side)*



Remove the cover of the Exhaust
Servo-motor.

Remove the Exhaust Servo-motor.




Exhaust Servo Eliminator Supplementary Manual



Honda CBR600RR 2007-2009 (ESE-H03)

Plug the ESE connector to the Exhaust Servo-motor connector.



Typical position for the Exhaust Servo Eliminator.

Secure the unit properly.

