

Exhaust Servo Eliminator Supplementary Manual



Kawasaki ZX-10R Ninja 2011-2014 (ESE-K01)

Remove the passenger seat.

Remove the upper seat cover.



Remove the main seat.



Unplug the Exhaust Servo-motor
connectors.

*(White, 3-pole triangular and Transparent,
2-pole connectors below main seat)*



Exhaust Servo Eliminator Supplementary Manual



Kawasaki ZX-10R Ninja 2011-2014 (ESE-K01)

Remove the Exhaust Servo-motor.

(Below main seat)



Plug the ESE connectors to the Exhaust Servo-motor connectors.



Typical position for the Exhaust Servo Eliminator.

Secure the unit properly.

