

Exhaust Servo Eliminator Supplementary Manual

Kawasaki ZX-6R Ninja 2005-2006 (ESE-K01)

Secure the bike on a stand.



Remove the black frame covers below
the main seat.

Remove the seats.



Locate the exhaust servo motor.




Exhaust Servo Eliminator Supplementary Manual



Kawasaki ZX-6R Ninja 2005-2006 (ESE-K01)

Remove the exhaust servo motor and unplug the exhaust servo motor connectors.



Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.

