

Exhaust Servo Eliminator Supplementary Manual



Suzuki GSR750 ABS 2011-2017 (ESE-S02)

Secure the bike on a stand.



Remove the seats and the side fairings.

Remove the fuel tank.



Locate and remove the Exhaust
Servo-motor.

Locate the Exhaust Servo-motor
connector.

(Gray, 6-pole connector below the fuel tank)



Exhaust Servo Eliminator Supplementary Manual



Suzuki GSR750 ABS 2011-2017 (ESE-S02)

Plug the ESE connectors to the Exhaust Servo-motor connectors.

Secure the unit properly.

