

Exhaust Servo Eliminator Supplementary Manual



Suzuki GSX-R1000 2012-2015 (ESE-S02)


Remove the Black covers from fuel tank.



Remove the main seat.



Lift up or remove the fuel tank.



Exhaust Servo Eliminator Supplementary Manual



Suzuki GSX-R1000 2012-2015 (ESE-S02)

Unplug the Exhaust Servo-motor connector.

Remove the Exhaust Servo-motor.

(Gray, 6-pole connector below the fuel tank on the left side)



Plug the ESE connector to the Exhaust Servo-motor connector.



Typical position for the Exhaust Servo Eliminator.

Secure the unit properly.

