

Exhaust Servo Eliminator Supplementary Manual



Suzuki GSX-R1000R 2017- (ESE-S03)

Secure the bike on a stand.



Remove the rear seat.



Locate the exhaust servo motor.




Exhaust Servo Eliminator Supplementary Manual



Suzuki GSX-R1000R 2017- (ESE-S03)

Remove the exhaust servo motor and unplug the exhaust servo motor connector.

(Grey, 6-pole connector under the rear seat.)



Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.

