

Exhaust Servo Eliminator Supplementary Manual

Suzuki DL1000 V-Strom 2017-2020 (ESE-S05)

Secure the bike on a stand.



Remove the seat.



Locate the exhaust servo motor.



Exhaust Servo Eliminator Supplementary Manual



Suzuki DL1000 V-Strom 2017-2020 (ESE-S05)

Remove the exhaust servo motor and unplug the exhaust servo motor connectors.

(Grey, 6-pole connector under the seat.)



Plug the ESE connectors to the exhaust servo motor connectors.

Secure the unit properly.

