

FI Cleaner Tool


Supplementary Manual

Benelli TRK 251 ABS 2018- (FIC-BE1)

Secure the bike on a stand.



Remove the seats and locate the white 6-pole diagnostic connector under the main seat.



Plug the FI Cleaner Tool connector to the diagnostic connector.

Turn the ignition key ON. The LED shows the current status of the maintenance.

