

## SUPPLEMENTARY MANUAL

for GIPRO-SO1

REMOVE THE MAIN SEAT.


LIFT UP OR REMOVE

THE FUEL TANK.



PLUG ATRE CONNECTORS IN-LINE WITH THE GEAR POSITION SENSOR CONNECTORS.

(WHITE, 3-POLE TRIANGULAR CONNECTORS UNDER FUEL TANK AT THE LEFT SIDE)



CONNECT ATRE RED WIRE TO ORANGE/GREEN WIRE OF REAR BRAKE SWITCH CONNECTOR.

(UNDER FUEL TANK AT THE RIGHT SIDE)





## TYPICAL POSITION FOR THE GEAR INDICATOR.

(TRE MODE: 6TH GEAR MAP)

