

Suzuki TL1000R

1998-2003



SUPPLEMENTARY MANUAL

for GIPRO-S01

REMOVE THE MAIN SEAT.




LIFT UP OR REMOVE
THE FUEL TANK.



PLUG ATRE CONNECTORS IN-LINE
WITH THE GEAR POSITION SENSOR
CONNECTORS.

(WHITE, 3-POLE TRIANGULAR CONNECTORS
AT THE RIGHT SIDE UNDER THE RIGHT FAIRING)



Suzuki TL1000R

1998-2003



**CONNECT ATRE RED WIRE TO
ORANGE WIRE OF
REAR BRAKE SWITCH CONNECTOR.**
(TRANSPARENT, 2-POLE CONNECTOR
AT THE RIGHT SIDE NEAR TO FRAME)



**TYPICAL POSITION FOR THE
GEAR INDICATOR.**
(TRE MODE: 6TH GEAR MAP)

