

GIPRO X-TYPE GEAR INDICATOR

Supplementary Manual



Suzuki GSF600 Bandit 2000-2004 (GPXT + GPX-S01)

Remove the main seat.

Remove the frame cover under the seat at the left side.




Remove the knob of fuel tap.

Lift up or remove the fuel tank.



Plug the GPX connectors in-line with the speed sensor connectors.

(Black, 3-pole connectors at the left side near the main relay)



GIPRO X-TYPE GEAR INDICATOR

Supplementary Manual



Suzuki GSF600 Bandit 2000-2004 (GPXT + GPX-S01)

Connect the GPX Black/Green wire to the Black/Blue wire of the ECU/ECM unit.

(Black, 8-pole connector at the left side below the rear fairing)



Typical position for the gear indicator.

Secure the unit properly.

