PS Eliminator
Supplementary Manual

Ducati Panigale V4 ABS TC 2024- (PSE-01)

Secure the bike on a stand.



Remove the seats.

Remove the tail fairings.

Remove the fuel tank.



Locate the stock PAIR (clean air) valve under the fuel tank.



Ducati Panigale V4 ABS TC 2024- (PSE-01)

Unplug the PAIR (clean air) valve connector.

Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

