PS Eliminator

Supplementary Manual



Kawasaki W800 2011- (PSE-01)

Secure the bike on a stand.



Locate the stock PAIR (clean air) valve under the fuel tank at the left side.



Unplug the connector.

Remove the fuel tank and remove the PAIR (clean air) valve.

(Green, 2-pole connector.)



PS Eliminator

Supplementary Manual



Kawasaki W800 2011- (PSE-01)

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

