

PS Eliminator Supplementary Manual

Kawasaki Z1000SX 2017- (PSE-01)

Remove the main seat.



Remove the fuel tank.



Remove the side fairings and the airbox.



PS Eliminator Supplementary Manual



Kawasaki Z1000SX 2017- (PSE-01)

Locate the stock PAIR (clean air) valve and unplug the connector.

(Green, 2-pole connector under the airbox.)



Remove the PAIR (clean air) valve.



Plug the PSE module into the wiring harness connector.

Secure the unit properly.

