

PS Eliminator Supplementary Manual




Kawasaki ZX-10R ABS TC 2011- (PSE-01)

Secure the bike on a stand.



Remove the seats and the side fairing on the right side.

Locate the stock PAIR (clean air) valve under the side fairing and unplug the connector.



Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

