PS Eliminator

Supplementary Manual



Kawasaki ZX-10R Ninja 2004-2010 (PSE-01)

Secure the bike on a stand.



Remove the seat and the side fairings.


Remove the fuel tank and the airbox.



Locate the stock PAIR (clean air) valve and unplug the connector.

Remove the PAIR (clean air) valve.

(White, 2-pole connector)



PS Eliminator

Supplementary Manual



Kawasaki ZX-10R Ninja 2004-2010 (PSE-01)

Plug the PSE module into the wiring harness connector.

Secure the unit properly

