

PS Eliminator

Supplementary Manual




Kawasaki ZX-6R Ninja 2009-2012 (PSE-01)

Remove the Black frame covers below fuel tank.


Remove the main seat.



Remove or lift up the fuel tank.



Remove the airbox.



PS Eliminator Supplementary Manual




Kawasaki ZX-6R Ninja 2009-2012 (PSE-01)

Locate the stock PAIR (clean air) valve and unplug the connector.

(Green, 2-pole connector under the airbox.)



Remove the PAIR (clean air) valve.



Plug the PSE module into the wiring harness connector.

Secure the unit properly.

