

# PS Eliminator Supplementary Manual




## MV Agusta Brutale 1078 2008 (PSE-01)

Secure the bike on a stand.



Remove the black cover under the fuel tank.

Locate the stock PAIR (clean air) valve and unplug the connector.



Remove the PAIR (clean air) valve.

Plug the PSE module into the wiring harness connector.

Secure the unit properly.

